

## **Pilot WF**

## **Product description**

This is a one component water borne acrylic emulsion coating. It is a versatile, fast drying product for exterior and interior use. It has a semi gloss finish with good colour and gloss retention. Dries down to 10 °C. Ideal for new construction or maintenance where fast dry to handle and over coating times are required. To be used as topcoat in atmospheric environments. It is part of a complete water borne system with a recommended Jotun water borne primer. This product is part of a complete system which is certified not to spread surface flames.

## Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements.

Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

## Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

## **Surface preparation**

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

When preparing new surfaces, maintaining already coated surfaces or aged coatings it is necessary to remove all contamination that can interfere with coating adhesion, and prepare a sound substrate for the subsequent product.

Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area using fresh water. Paint solvents (thinners) shall not be used for general degreasing or preparation of the surface for painting due to the risk of spreading dissolved hydrocarbon contamination. Paint thinners can be used to treat small localized areas of contamination such as marks from marker pens. Use clean, white cotton cloths that are turned and replaced often. Do not bundle used solvent saturated cloths. Place used cloths into water.

## **Coated surfaces**

## Organic primers/intermediates

The surface of previous coats shall be free from contamination by water, hydrocarbon based products, wax, mud, mortar droppings and loose, chalked and flaking coating. Inspect the surface for oil, grease and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the detergent and before it dries, wash the treated area using plenty of fresh water.

When applied on coatings past maximum over coating interval light abrading may be required to achieve proper intercoat adhesion.

Date of issue: 17 June 2022 Page: 1/7



## **Application**

## Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

Air temperature 10 - 50 °C Substrate temperature 10 - 40 °C Relative Humidity (RH) 10 - 75 %

The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

## **Product mixing**

### **Product mixing**

Single pack

### **Induction time and Pot life**

The temperature of base and curing agent is recommended to be 18  $^{\circ}\text{C}$  or higher when the product is mixed.

## Thinner/Cleaning solvent

Thinner: Water

## **Application data**

## **Spray application**

## Airless Spray Equipment

Pump ratio (minimum): 32:1

Pressure at nozzle (minimum): 150 bar/2100 psi

Nozzle tip (inch/1000): 13-19

Nozzle output (litres/minute): 1.3-1.9

Filters (mesh): 70

Date of issue: 17 June 2022 Page: 2/7



Several factors influence, and need to be observed to maintain the recommended pressure at the nozzle. Among factors causing pressure drop are:

- extended hoses or hose bundles
- extended hose whip-end line
- small internal diameter hoses
- high paint viscosity
- large spray nozzle size
- inadequate air capacity from compressor
- incorrect or clogged filters

#### Other application tools

#### **Brush application**

Suitable for application with brush. Use a high quality, clean natural or synthetic bristle brush with proper shape and size. When used as primer coat, a stiff brush is recommended to secure proper substrate wetting. When used as a finish coat a more long haired brush is recommended to improve flow and appearance. To achieve specified dry film thickness it may be necessary to apply multiple coats.

#### Roller application

Suitable for application with roller. Use a properly sized, high quality, clean roller with natural or synthetic cover. Pre-wash new rollers in proper thinner to remove loose fibres. Roller is not recommended for application of primer coat. Addition of small volumes (5-10 %) of thinner will improve appearance when used as finish coat. To achieve specified dry film thickness it may be necessary to apply multiple coats.

## Film thickness per coat

## Typical recommended specification range

Dry film thickness 40 - 80  $\mu m$  Wet film thickness 105 - 205  $\mu m$  Theoretical spreading rate 9.8 - 4.9  $m^2/l$ 

This product can be applied up to 50 % higher than maximum specified film thickness without loss of technical properties.

Application at substrate temperatures above 40°C and in direct sunlight may cause surface defects.

### Film thickness measurement

## Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). The measurements should be done as soon as possible after application.

Fast drying paints may give incorrect (too low) readings resulting in excessive dry film thickness. For multi layer physically drying (resoluble) coating systems the wet film thickness comb may give too high readings resulting in too low dry film thickness of the intermediate and top coats.

Use a wet-to-dry film calculation table (available on the Jotun Web site) to calculate the required wet film thickness per coat.

### Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 mm from the weld.

## Ventilation

Date of issue: 17 June 2022 Page: 3/7



Sufficient ventilation is very important to ensure proper drying/curing of the film.

### **Coating loss**

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

#### **Pre-commissioning considerations**

Ultimate dry film hardness will be reached later than the time stated for dried/cured for service. Suitable procedure for stacking of coated products must be considered, depending on environmental conditions.

## **Drying and Curing time**

Substrate temperature	10 °C 23 °C 40 °C
Surface (touch) dry	30 min 25 min 15 min
Walk-on-dry	2 h 1 h 1 h
Dry to over coat, minimum	3 h 1.5 h 1 h

Drying and curing times are determined under controlled temperatures and relative humidity below 75 %, and at average of the DFT range for the product.

The recommended Relative Humidity range is 30-75 %.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The recommended shortest time before the next coat can be applied.

# **Maximum over coating intervals**

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water cleaning using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

## Areas for atmospheric exposure

Date of issue: 17 June 2022 Page: 4/7



Average temperature during drying/curing	10 °C 23 °C 40 °C
Itself	extended extended

## Other conditions that can affect drying / curing / over coating

## Adding anti-skid to the coating system

Anti skid aggregate should only be added in the final coat, and should not be used in single coat systems. Spread the aggregate evenly on the surface before half of time to Surface dry. Use Jotun Anti-skid, fine particle size (180 - 250  $\mu$ m), for coatings applied in 50 to 150  $\mu$ m DFT. The recommended usage is 1.5 - 2.0 kg per 10 litres of paint.

### Water/Moisture contamination

If the wet coating is exposed to relative humidity above 85% or to moisture before the coating is at least Walk-on-dry, then blushing may occur. Blushing will cause fading of bright colours, and will affect the gloss. Provided the coating is fully dried/cured the protective properties will not be affected.

All affected areas should be lightly sanded, cleaned and recoated.

### Repair of coating system

#### Damages to the coating layers:

Prepare the area through sandpapering or grinding, followed by thorough cleaning/vacuuming. When the surface is clean and dry the coating may be over coated by itself or by another product, ref. original specification.

Always observe the maximum over coating intervals. If the maximum over coating interval is exceeded the surface should be carefully roughened in order to ensure good intercoat adhesion.

### Damages exposing bare substrate:

Remove all rust, loose paint, grease or other contaminants by spot blasting, mechanical grinding, water and/or solvent washing. Feather edges and roughen the overlap zone of surrounding intact coating. Apply the coating system specified for repair.

## **Coating film continuity**

When required by the specification, the coating shall be tested for film discontinuity according to ASTM D 5162, test method A or B as appropriate for the actual dry film thickness. All recorded defects shall be repaired by best practical means.

# **Quality assurance**

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation
- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAO
- Confirm that the required surface preparation standard has been achieved and is held prior to coating application
- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application
- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing
- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle
- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination
- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious pinholes, excessive dry spray, heavy brush marks and excessive film build

Date of issue: 17 June 2022 Page: 5/7



- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

## **Caution**

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

### **Health and safety**

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

### **Accuracy of information**

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

### **Colour variation**

When applicable, products primarily meant for use as primers or antifoulings may have slight colour variations from batch to batch. Such products and epoxy based products used as a finish coat may chalk when exposed to sunlight and weathering.

Colour and gloss retention on topcoats/finish coats may vary depending on type of colour, exposure environment such as temperature, UV intensity etc., application quality and generic type of paint. Contact your local Jotun office for further information.

## **Reference to related documents**

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

# Symbols and abbreviations

min = minutes

h = hours

d = days

°C = degree Celsius

o = unit of angle

 $\mu m$  = microns = micrometres

g/I = grams per litre

g/kg = grams per kilogram

 $m^2/I = square metres per litre$ 

 $mg/m^2 = milligrams per square metre$ 

psi = unit of pressure, pounds/inch2

Bar = unit of pressure

RH = Relative humidity (% RH)

UV = Ultraviolet

DFT = dry film thickness

WFT = wet film thickness

TDS = Technical Data Sheet

AG = Application Guide

SDS = Safety Data Sheet

VOC = Volatile Organic Compound

MCI = Jotun Multi Colour Industry (tinted colour)

RAQ = Required air quantity

PPE = Personal Protective Equipment

EU = European Union

UK = United Kingdom

EPA = Environmental Protection Agency

ISO = International Standards Organisation

ASTM = American Society of Tocting and Materia

 $\mathsf{ASTM} = \mathsf{American} \ \mathsf{Society} \ \mathsf{of} \ \mathsf{Testing} \ \mathsf{and} \ \mathsf{Materials}$ 

AS/NZS = Australian/New Zealand Standards

NACE = National Association of Corrosion Engineers

SSPC = The Society for Protective Coatings

PSPC = Performance Standard for Protective Coatings

IMO = International Maritime Organization

Date of issue: 17 June 2022 Page: 6/7



ASFP = Association for Specialist Fire Protection

## **Disclaimer**

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.

Date of issue: 17 June 2022 Page: 7/7